

## **Skirt Exhaust Cut-Out Kit Instructions**

- The dedicated Skirt Panel must be properly installed on the vehicle as if you were camping (The Skirt Panel that this kit will be installed on will always need to be placed in the same location so that your Exhaust Pipe will vent correctly)
- Now that the Skirt Panel is attached to your vehicle, locate the exhaust pipe and mark an (X) on the Skirt Panel in-center with the exhaust pipe
- Remove the Skirt Panel from the vehicle, and place the Skirt Panel on a flat and sturdy surface (i.e., floor or table) with a piece of cardboard between the Skirt and the sturdy surface
- Place one ring on the Skirt Panel surface with the (X) that you previously marked in the center of the ring
- Make sure you have no wrinkles in the Skirt Panel with the (X) in the middle of the Ring. Use the provided pop-rivets to poke through all 4 of the Ring's pop-rivet 1/8 holes.
- Cautiously lift the Skirt Panel with the 1<sup>st</sup> Ring still intact
- With all 4 rivets inserted through the 1<sup>st</sup> Ring and Skirt Panel, align the holes of the 2<sup>nd</sup> Ring and push it flush against the Skirt Panel making sure that the rivets pass through the holes of the 2<sup>nd</sup> Ring.
- You now will need your Rivet-gun with an 1/8 tip
- Apply pressure to both of the Rings so that the Skirt Panel squeezes together between them evenly.
- Take your rivet-gun and begin to squeeze the rivets so they securely fasten both Rings tightly together.
- Once you have made sure that the pop rivets are securely fastened, take a razor knife and begin to cut out the fabric located in the "INNER CIRCLE" of the ring. The inner circle of the ring is the portion of the Skirt Panel that you previously marked the (X) in.
- Having completed all of these steps successfully, when installing your RV WindSkirt properly, you should have an open ring around your vehicle's exhaust pipe.

**Tools required; Marking Pen, Pop Rivet Tool and Razor Knife**

**If you have questions, please call the number below.**

**“The RV WindSkirt Exhaust Cut-Out-Kit Should be installed by a qualified person”**

820 Park Row, #552 Salinas, CA 93901 (831) 998-8677 or Toll Free 800-591-4737 [www.rvWindSkirt.com](http://www.rvWindSkirt.com)